



## Heating Room Thermostat

### User Guide

Model: BHT-1000



### Welcome

Thank you for your purchase.  
Your new thermostat will provide uniform and comfortable temperature control throughout every room in your property. We bring together technology, craftsmanship and the highest quality materials to provide you with a safe, reliable product combined with sleek, contemporary design. Please read this installation/programming manual for comprehensive instructions on installing and operating your thermostat. Please ensure a suitably qualified person installs your thermostat and complies with all local regulations.

### Contents

Thermostat	1pc
Screws	1pc
Installation/programming manual	1pc
Wall plate	1pc
3m External (Floor) Sensor	1pc

### Warranty

Your thermostat carries an 18 month warranty from date of purchase. Service outwith the warranty period may incur a charge.


### Your thermostat

The BHT-1000 range has been developed to control electric underfloor or water heating systems. These units are designed for use in commercial, industrial, civil and domestic properties.

### Features

- Simple installation
- Acrylic face plate
- Large, backlit display
- Sleek, contemporary design
- Elegant chrome frame
- Feather touch control panel
- 5+2 six period per day programming
- Simple, one-touch temperature control over-ride
- Pre-set temperatures maintained within +/- 1°C
- Internal and external sensors allow control of both air and/or floor temperatures
- Suitable for installation in a standard single pattress box or European 60mm round box
- RS485/MODBUS communication optional

### Home screen quick reference



### Technical Data

Sensor: NTC  
Accuracy:  $\pm 1^{\circ}\text{C}$   
Set Temp. Range:  $5\text{--}35^{\circ}\text{C}$   
Room Temp. Range:  $5\text{--}99^{\circ}\text{C}$   
Power Consumption:  $< 1.5\text{W}$   
Timing Error:  $< 1\%$   
Power Supply:  $95 \sim 240\text{VAC}$ ,  $50 \sim 60\text{Hz}$   
Current Load:  $3\text{A}$  (water heating),  
 $16\text{A}$  (electric heating)  
Shell material: PC+ABS (flame retardant)  
Dimension:  $86\text{mm} \times 86\text{mm} \times 13.3\text{mm}$   
Ambient Temp.:  $0\text{--}45^{\circ}\text{C}$ ,  $5\text{--}95\%\text{RH}$   
(Non-condensing)  
Storage Temp.:  $-5\text{--}55^{\circ}\text{C}$   
Installation Hole distance:  $60\text{mm}$

### Operation/programming

#### 1. Power on/off

Press to turn on/off.

#### 2. Adjusting/setting the temperature

Press to set the desired temperature.

#### 3. Adjusting/Setting the clock

Touch the icon to set minute, hour and weekday (1 = Monday, 2 = Tuesday etc.) by using the arrows. Press once more to confirm and exit.

#### 4. Locking your thermostat

Press and hold the and arrows for 5 seconds to lock/unlock your thermostat.

#### 5. Adjusting/setting the program schedules

Your thermostat provides six scheduled heating periods each day – three Comfort periods - 1, 3 & 5 (the temperature required when room is occupied) and three Economy periods – 2, 4 & 6 (the temperature required when room is unoccupied). You can set both the time **and** temperature for each of these six daily periods. Adjusting/setting the schedules can only be carried out when in program mode;  
Touch M (mode) to change between manual mode and programme mode. In manual mode,

☞ will show in the bottom left of the screen.

Touch and hold the icon ⌚ until the weekday schedule settings appear (1 2 3 4 5 will show along the top of the screen).

Use the ▲ and ▼ arrows to adjust the time for the 1st (Comfort) period

Press the icon ⌚ and use the ▲ and ▼ arrows to set the temperature for the 1st period.

Repeat this process for periods 2 – 6.

Press the icon ⌚ once more to enter the weekend schedule settings (6 & 7 will show along the top of the screen).


Repeat the above process to set the weekend schedule. Press ⌚ once more to confirm and exit.

### Default settings for program schedule

Time display	WEEKDAY (MON. – FRI.)		WEEKEND (SAT. – SUN.)	
	TIME	TEMP.	TIME	TEMP.
Period 1 (Comfort)	06.00 waken	20°C	06.00 waken	20°C
Period 2 (Economy)	08.00 leave	15°C	08.00 leave	20°C
Period 3 (Comfort)	11.30 home	15°C	11.30 home	20°C
Period 4 (Economy)	13.30 leave	15°C	13.30 leave	20°C
Period 5 (Comfort)	17.00 home	22°C	17.00 home	15°C
Period 6 (Economy)	22.00 bed	15°C	22.00 bed	15°C

### Wiring your thermostat

### Wiring your thermostat



#### Please note:

Do not over-tighten the terminals in your thermostat as damage may occur.

## 6. System function settings

With power off, press and hold both M and ⌚ for 5 seconds to enter the System Functions. Press M to scroll through the available functions, and use the ▲ and ▼ arrows to change the available options. Your thermostat will automatically exit the System Functions settings after approximately 15 - 20 seconds of inactivity. All settings are automatically confirmed when power is switched on


Code	Function	Setting & options	Default
1	Air temperature calibration	Range is -9°C to +9°C for internal sensor	-2
2	Switching differential	Range is 0°C to 5°C The number of degrees above/below set temperature before switching on/off When default is set to 1°C the thermostat will switch on 0.5°C below the set temperature and will switch off 0.5°C above the set temperature.	1
3	Button locking	00: = All buttons will lock except the Power button 01: = All buttons will lock	01
4	Sensor selection	In = control temperature using the internal sensor Ou = control temperature using the external (floor) sensor Al = control temperature using internal sensor to control temperature, and external sensor to limit the floor temperature	In for GA Al for GB
5	Minimum temperature setting	Range is 5°C - 15°C.	5
6	Maximum temperature setting	Range is 15°C - 45°C.	35
7	12/24 hour clock	00: 12h: = 12 Hour clock 01: 24h: = 24 hour clock	01
8	Display Mode	00: display both set temp. and room temp. 01: display set temp. only	00
9	Minimum floor temperature protection setting	Range is 0°C - 20°C. When chosen floor temperature is reached, the system will automatically switch off. This facility is used to protect delicate floor coverings.	0
A	Maximum floor temperature protection setting	Range is 10°C - 70°C. When chosen floor temperature is reached, the system will automatically switch off. This facility is used to protect delicate floor coverings.	26
B	Backlight On Time	3-99S.	10
C	Return to factory setting	00: Normal Status 01: Return to factory setting	00

#### Please note:

1. "Err" on your thermostat indicates a fault without the external (floor) sensor. Your thermostat will be inoperative until the error is rectified.
2. When sensor selection is "AL" (option 3 above) the room temperature will be displayed on your thermostat by default. The floor temperature can be displayed temporarily by pressing the ▼ button for three seconds. Your thermostat will revert to display the room temperature after several seconds.


## Installing your thermostat

Your thermostat is suitable for installation within a standard 86mm pattress box or European 60mm round pattress box.




(Fig 1)

1. Connect power supply, load and external (floor) sensor into the appropriate terminals if there is external sensor. (see "Wiring your thermostat" for details).




(Fig 2)

2. Secure thermostat wall plate to pattress box using the supplies screws



(Fig 3)



(Fig 4)

4. Installation complete.

3. Connect body of thermostat to the wall plate

**RISK OF ELECTRICAL SHOCK.** Disconnect/isolate power supply prior to making electrical connections. Contact with high voltage components can cause electrical shock, severe injury or death.